



ASSEMBLY INSTRUCTIONS

Anti overturning tension belt




STEP 1

Anti overturning tension belt




STEP 2


Anti overturning tension belt




STEP 3



















STEP 4



Anti overturning tension belt



I	1PC	
2	1PC	
3	1PC	
4	1PC	
A	1PC	
B	1PC	
C1	1PC (FRONT)	
C2	1PC (FRONT)	
D1	1PC (BACK)	
D2	1PC (BACK)	
E	1PC	
F	1/4"*12MM*6PCS	
G	∅6.5MM*2PCS	
H	∅6.5MM*2PCS	
I	16PCS	
J	1PC	
K	4PCS	